Testing Equipment for Construction Materials

Find My Gauge Kit

Nuclear Gauge Find My Gauge Kit

Now with Humboldt's New Find My Gauge Tracking Kit, you can locate your gauge through any computer or mobile device! With this amazing GPS tracker, your gauges can be tracked to see where they are!

No need to upgrade your Nuclear Gauge to track it. Simply install the GPS tracker inside your Gauge and with a few simple steps, you will be able to find your gauge! Humboldt will provide the GPS tracker and all the necessary mounting hardware, cabling and instructions! It's that simple!

Features:

- Outdoor and indoor use
- Built-in, sensitive, vibration sensor even if a slight vibration for 3 seconds, the device will send alarm to owner.
- Geo-fence will help you make safe area. When the gauge is out of the safe area, the device will send alarm to owner.
- Highly waterproof
- 6 month server storage to view historical routes in APP & Web platform at any time.
- 5000mAh rechargeable battery device can work up to 7 days for 24/7 monitoring. (Depending on the number of inquires per day the device will work longer.)
- Includes easy access charging port no need to disassemble the gauge
- Tracking software can be installed to your personal computer or phone.
 Free of charge no contract required.
- SIM Card sold separately. As little as 5 dollars a month in USA and data sim card are available around the world.





Find My Gauge Kit



GPS Shown inside of Nuclear Gauge



Inside of Nuclear Gauge



Easy Access Charging Port

GPS Asset Tracker (Find My Gauge) Specifications:	
Dimensions	3.5"x2.8"x0.8" (90mm x 72mm x 22mm)
Weight	168g
Network	GSM / GPRS
Band	850/900/1800/1900Mhz
GPS Sensitivity	-159dBm
GPS Accuracy	5m
Wall Charger	Input: 110-220V Output: 5V-1A
Battery	Chargeable 3.7V 5000mAh Li-ion Battery
Stand By	90 Days
Time To First Fix	Cold Status 45s Warm Status 35s Hot Status 1s
Storage Temp.	-40°F to +185°F (-40°C to +85°C)
Operation Temp.	-4°F to +131°F (-20°C to +55°C)
Humidity	5%95% non-condensing

GPS Asset Tracker (Find My Gauge) Options:	
HS-201050	Find My Gauge Kit With GPS, SIM Card, Wall AC charger & Hardware
HS-201055	Same as HS-201050 with extra NiMH Batteries
HS-201060	Same as HS-201055 with MotherBoard
HS-201065	Same as HS-201050 with EZ-2 Front Panel Assembly & MotherBoard
HS-201070	Same as HS-201065 with extra NiMH Batteries
HS-201075	Same as HS-201050 with NX Front Panel Assembly & MotherBoard



Humboldt Scientific, Inc. www.humboldtscientific.com 2525 Atlantic Avenue Raleigh, North Carolina 27604 U.S.A. Toll Free: 1.800.537.4183 Phone: 1.919.833.3190 Fax: 1.919.833.5283 Email: hsi@humboldtmfg.com